

**HEAVY DUTY COMBINATION BRAKE LATHE  
MODEL 8989**

**OPERATIONS AND MAINTENANCE MANUAL**

 **Accu Industries, Inc:**  
P.O. BOX 15540 / RICHMOND, VA 23227  
11126 AIR PARK ROAD / ASHLAND, VA 23005  
804-798-8922 FAX 804-798-6742

**CONGRATULATIONS** ... You have just purchased the finest brake lathe in the world today. Your ACCU-Turn Lathe is a high quality, precision engineered product designed to give you years of trouble free service.

To familiarize yourself with all its features, please take the time to **Read This Owner's Manual Carefully**. Store this manual in a safe place for future reference.

It is important that you **Fill Out The Enclosed Warranty Card and Mail It Back to our Headquarters**. This is of primary importance not only for any authorization of warranty service, but also proper parts shipments to match the model of your machine and also to receive any future product updates and information.

It is also important that you **Record the Model Number, Serial Number and Other Vital Information Here**. These numbers are located on the back of your lathe.

Dealer \_\_\_\_\_ Purchase Date \_\_\_\_\_

Model \_\_\_\_\_ Serial Number \_\_\_\_\_

**ACCU-TURN**  
**HEAVY-DUTY COMBINATION BRAKE LATHE**  
**MODEL 8989**  
**OPERATIONS AND MAINTENANCE MANUAL**

TABLE OF CONTENTS

List of Standard Equipment .....	1
Brake Lathe Specifications .....	1
Acceptance from Carrier .....	2
Safety Information .....	2
Assembly of Lathe .....	7
Operation Procedures	
Inspection .....	8
Passenger Drums .....	8
Passenger Disc Rotors .....	10
Flywheels .....	12
Heavy-Duty Operation .....	14
Diagrams .....	19
Parts List .....	24
Additional Diagrams .....	30

When ordering parts, please give the Serial # of your machine and the Date Purchased; this will help in expediting your order.

FOR YOUR RECORDS AND INFORMATION

DATE RECEIVED \_\_\_\_\_

SERIAL # \_\_\_\_\_

04/97 200  
#435050

**STANDARD ACCESSORIES INCLUDED WITH THE 8989 HEAVY-DUTY COMBINATION BRAKE LATHE**

- 1 Draw Bar with Hex Nut and Washer
- 1 T-Bolt with Nut and Washer
- 1 Spacer Block for Twin Cutter Attachment
- 2 Large Bell Clamps
- 2 Small Bell Clamps
- 3 Centering Cones for Floating Rotors & Drums
- 3 Silencers
- 5 Double Taper Radius Adapters
- 1 Twin Cutter with Tool Holders, for Rotors
- 1 Boring Bar with Tool Holders, for Drums
- 1 Standard 1" Arbor
- 1 Arbor Nut
- 1 Arbor Spring
- 1 1" Spacer
- 1 Set of Alignment Washers
- 3 Wrenches 1 1/2", 7/8", 3/8"

**8989 HEAVY-DUTY COMBINATION BRAKE LATHE SPECIFICATIONS**

115 Volt	60 --- Hertz	1 Phase	10.0 Amps
Rotor Capacity -----	4" to 24"		
Maximum width of surface -----	4 1/2"		
Maximum thickness -----	2 1/4"		
Drum Capacity -----	6" to 28"		
Friction Surface Capacity -----	10"		
Flywheel Capacity -----	6" to 24"		
Friction Surface Capacity -----	6"		
Maximum Weight:			
On 1" Arbor -----	150 lbs.		
On 1 7/8" Arbor -----	300 lbs.		
On 1 7/8" Arbor w/Outboard Support --	600 lbs.		
Spindle Speed RPM -----	52/105		
Feeds Per Spindle Revolution:			
Disc -----	.003/.006		
Drum -----	.0046/.0092		
Motor -----	1 Horsepower		
Weight:			
Net -----	500 lbs.		
Ship Wt. -----	560 lbs.		

## ACCEPTANCE FROM TRANSPORTATION CARRIER

Carefully inspect all items received in this shipment. If there is damage or evidence of mishandling in transit, determine the extent of damage and notify the transit company as well as ACCU Industries, Inc. immediately. Although we are not responsible for damage incurred in transit, we will assist in the preparation and filing of claims.

## SAFETY INFORMATION

This manual has been prepared for the operator and those responsible for the maintenance of the brake lathe. Its purpose, aside from proper maintenance and operations, is to promote safety through the use of accepted practice.

### READ AND UNDERSTAND THE SAFETY AND OPERATING INSTRUCTIONS COMPLETELY BEFORE OPERATING THE MACHINE

In order to obtain maximum life expectancy and efficiency from your brake lathe, follow the operating instructions and maintenance manual carefully.

The specifications put forth in this manual were in effect at the time of publication. However, owing to ACCU Industries' policy of continuous improvement, changes to the specifications may be made at any time without obligation on the part of ACCU Industries, Inc.

### Safety Instructions

1. Read, understand and follow the safety and operating instructions found in this manual. Know the limitations and hazards associated with operating the machine. A safety rules decal is installed on the machine to serve as a reminder of basic safety practice. It should be read before attempting to use the brake lathe.
2. Special Precautions: This ACCU-Turn brake lathe was designed to machine the portions of the brake drum, disc brake rotor and flywheel surfaces that come in contact with the friction material. When used according to the instructions herein, this lathe will perform satisfactorily within the workpiece size range designated for this model.

During the machining operation, the workpiece rotates. Be especially cautious of rotating wheel lugs, spokes and mounted accessories. During machining, material removal may

cause a sharp edge to be generated, where a chamfer or radius previously existed. Use care in handling machined parts.

3. Securing the Machine: The model 8944 weighs approximately 470 pounds and must be bolted to an ACCU-TURN Heavy duty Floor Stand or a bench capable of supporting the machine, its accessories and workpiece.
4. Grounding the Machine: In the event of a malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. The lathe is equipped with an electric cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into a matching outlet that is properly installed and grounded in accordance with all local codes and ordinances.

Do not modify the plug provided. If the plug will not fit the outlet, have the proper outlet installed by a qualified electrician.

Improper connection of the equipment-grounding conductor can result in a risk of electric shock. The conductor with insulation having an outer surface that is green with or without yellow stripes is the equipment-grounding conductor. If repair or replacement of the electric cord or plug is necessary, do not connect the equipment-grounding conductor to a live terminal.

Check with a qualified electrician or service personal if the grounding instructions are not completely understood, or if in doubt as to whether the lathe is properly grounded.

Use only 3-wire extension cords that have 3-prong grounding plugs and 3-pole receptacles that accept the lathe's plug.

Repair or replace damaged or worn cord immediately.

This lathe is intended for use on a circuit that has an outlet that looks like the one illustrated in Sketch A in Figure 4.1. The tool has a grounding plug that looks like the plug illustrated in Sketch A in Figure 4.1. A temporary adapter, which looks like the adapter illustrated in Sketches B and C, may be used to connect this plug to a 2-pole receptacle as shown in Sketch B if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet can be installed by a qualified electrician. The green-colored rigid ear, lug, or other grounding means extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box.

5. Use Proper Extension Cord: Make sure your extension cord is in good condition. When using an extension cord, be sure to use one heavy enough to carry the current the lathe will draw. An undersized cord will cause a drop in line voltage resulting in a loss of power and overheating. Table 5.1 shows the correct size to use depending on the cord length. If in doubt, use the next heavier gage. The smaller the gage number, the heavier the cord.
6. Eye Safety: Wear an approved safety face shield, goggles, or safety glasses. (Ordinary eyeglasses are not safety glasses and do not provide the degree of protection necessary.) If the operation or area is dusty a face or dust mask should be used.
7. Personal Protection: Before operating the machine, remove tie, rings, watches, and other jewelry, and roll up sleeves above the elbow. Remove all outer loose clothing and confine long hair. Protective type footwear must be worn. Hearing protectors must be used where noise exceeds the level of exposure allowed in Section 1910.95 of the OSHA Regulations.

**DO NOT WEAR GLOVES**

8. DO NOT OPERATE MACHINE WITHOUT ITS GUARD(S) IN PLACE AND IN WORKING ORDER.
9. Do Not Use Lathe in Dangerous Environment: Don't use the lathe in damp or wet locations, or expose the lathe to rain. Keep the work area well lighted.
10. Work Area: Keep the floor around the machine clean and free of foreign materials. ACCU Industries recommends the use of anti-skid floor strips where the operator normally stands, and that each machine has its own work area marked off. Make certain that the work area is well-lighted and ventilated. Provide for adequate work space around the machine. The work area should not be readily accessible to anyone except the operator.
11. Do Not Overreach: Maintain a balanced stance and keep your body under control at all times.
12. Hand Safety: Keep hands away from moving parts when the machine is under power. Never clear chips or debris when the machine is under power and never use your hands to clear the chips. Never use compressed air to clean machine; use only a soft bristle brush or vacuum cleaner.
13. Spindle Rotation: Rotate spindle by hand before applying on

power. Be sure that the rotation of the spindle is correct.

14. Machining Preparation: Tighten all locks before operating the lathe. Be sure workpiece is secured. Remove adjusting keys and wrenches. Be sure to check to see that all adjusting wrenches are removed from the lathe before turning the machine
15. Check Damaged Parts: Before further use of the lathe, a guard or other part that is damaged should be carefully checked to determine if it will operate properly and perform its intended function. Check for alignment of moving parts, binding of moving parts, breakage of parts, mounting, and any other conditions that may affect the lathe's operation. A guard or other part that is damaged should be properly repaired or replaced.
16. Maintain Tools with Care: Keep tools sharp and clean for best and safest performance. follow instructions for lubricating and changing accessories.
17. Avoid Accidental Starting: Make certain that the motor switch is in the "Off" position before connecting power to the machine.
18. Never Stand on Lathe: Serious injury could occur if the lathe is tipped or if the cutting tool is unintentionally contacted.
19. Machine Capacity: Do not attempt to use the machine for other than passenger car and light truck drums, discs and flywheels, or for operations for which the machine was not intended.
20. Careless Acts: GIVE THE WORK YOU ARE DOING YOUR UNDIVIDED ATTENTION.
21. Disconnect Electrical Power before performing any service, maintenance, or changing of accessories, adapters, or workpieces on machine.
22. Job Completion: If the operator leaves the machine area for any reason, the machine should be turned off, and the spindle brought to a complete stop before the operator departs. In addition, if the operation is complete, the operator should clean the machine and work area. NEVER CLEAN THE MACHINE WITH THE POWER ON.
23. Replacement Parts: Use only ACCU-TURN replacement parts and accessories, risk of injury may result if accessories other

than those recommended are used. USE OF PARTS OTHER THAN ACCU-TURN PARTS WILL VOID THE WARRANTY.

24. Misuse: Do not use the machine for other than its intended use. If used for other purposes, ACCU Industries Inc., disclaims any expressed or implied warranty, and holds itself harmless for any injury or loss that may result.




Fig. 4.1

Amper Rating	Volts	Total length of cord in feet			
	120 V	25 ft.	50 ft.	100 ft.	150 ft.
More Than	Not More Than	AWG			
12	16	14	12	Not Recommended	

Table 5.1

## **ASSEMBLY OF BRAKE LATHE**

### **Setting Up Brake Lathe For Operation**

All machine surfaces are covered with a protective coating before packaging. They must be thoroughly cleaned with solvent. The spindle, arbor taper and mounting surface on top of ways should also be cleaned and wiped dry.

Install the draw bar in the arbor and screw in snugly. Insert the draw bar through the spindle, and align the match marks on the arbor and spindle. Install the washer and nut on the rear of the draw bar, and tighten to 55 foot pounds. Mount the drum boring bar or rotor twin cutter on the machine; make sure all inserts, bolts, and set screws are tight.

Machine must be securely fastened to work bench surface before operating. Four mounting holes on the base are provided for this purpose. Bolts are not provided.

### **Lubrication**

Lubricate ways by oiling felt wipers on the end of cross slide every week with SAE 10W oil or equivalent, and check gear box by removing vented plug on top rear of housing. Oil level should be about 2 inches from the top. If needed, use MOBIL Synthetic Gear Oil - #411488 or equivalent. Capacity is one quart. DO NOT OVER-FILL.

### **Electrical Information**

Standard motors on this machine are wired to 115 volt, 60 cycle, single phase. Check electrical input plate on rear of machine. The ON-OFF switch is located to the right end of the main housing. Never operate machine unless power supply agrees with electrical plate rating and machine is properly grounded.

## **ACCU-TURN 8989 HEAVY-DUTY COMBINATION BRAKE LATHE**

### **PASSENGER CAR AND LIGHT TRUCK OPERATION PROCEDURES**

#### **Inspection of Brake Drums, Disc Rotors & Flywheels Before Machining**

**IMPORTANT:** The maximum amount of metal removed from the finished workpiece should never exceed the manufacturer's specifications. It is dangerous to operate a vehicle with a drum, rotor or flywheel which has had more material removed than is allowed. Proper operation can not be established if these specifications have been exceeded. ACCU Industries, recommends that each workpiece be checked for size before mounting on the machine and after machining.

Passenger car and light truck drums and rotors should be machined with a brake lathe operating at 100 RPM's. The proper pulley selection is a drive belt in a large pulley at the motor and a small pulley at the gear box. Always install the belt guard before starting the machine.

#### **Mounting of Hubless Drums**

1. Clean and check all surfaces for flatness that will come in contact with centering cones and/or bell clamps to ensure solid mounting.
2. Cleaning and properly mounting the drums prior to machining will ensure a minimum of stock removal and more satisfactory brake operation and better surface finish.
3. Excessive run out or wobble of the drum after it has been properly cleaned and mounted on the arbor may indicate severe damage to the drum and therefore should not be used for further service.
4.
  - a. Select proper size bell clamps and slide one on the arbor.
  - b. Slide spring on the arbor.
  - c. Find the centering cone adapter that fits the center hole of the drum and slide it on the arbor.
  - d. Slide the drum on the arbor and then the other bell clamp.
  - e. Add necessary spacers (double tapered radius adapters may be used as spacers), alignment washers, hex nut and tighten securely. Do not jerk or over tighten. (See example on page 19)
5. If arbor appears distorted check for rust, burrs or chips on cones, drum, bell clamps, spacers, arbor or other mating surfaces.

### **Mounting the Hubbed Drum**

1. Select the double tapered radius adapter that properly fits the inside of the large bearing race. It should sit in the race similar to a bearing and move side to side in all directions easily. If it binds in any direction, this is an indication of an incorrect adapter selection or a damaged bearing race. Correct problem before proceeding.
2. Slide the double tapered radius adapter all the way onto the arbor. If the drum contacts the lathe a spacer may be required between the double tapered adapter and lathe.
3. Using the same steps as in 1., find the double tapered radius adapter for the outside race.
4. Install the drum and position it on the back double tapered radius adapter and then slide the front double tapered radius adapter on the arbor and into the front race.
5. Use adapters or spacers as necessary to space out to the end of the arbor. (See example on page 20)
6. Add alignment washers, hex nut and tighten. Do not shock load or jerk.
7. WRAP RUBBER SILENCER BAND AROUND DRUM, STARTING WITH THE PLAIN END AND MAINTAIN TENSION UNTIL THE CLIP IS SECURED. DO NOT ATTEMPT TO MACHINE DRUMS WITHOUT USING THE SILENCER BAND. Silencer should be nearest open side of drum.
8. If arbor appears distorted, check for dirty or damaged mounting surfaces and/or adapters. Loosen and re-tighten arbor nut as described above in Step 6.

### **Machining Hubless and Hubbed Drums**

1. Position the tool bar so that the 45 degree angle tool bit slot is toward the drum, with the capscrew to the top. TOOL BAR EXTENSION SHOULD BE KEPT TO A MINIMUM. Boring bar must not be rotated upward or downward.
2. For extra small diameter drums, set the tool bar at an angle towards the arbor while extending the tool bar holder outward from the tool bar.
3. Turn on the machine. Slowly advance the tool bar in the drum and contact the point of the greatest wear.
4. Note the reading on the calibrated handwheel; back out one full turn and move to the rear of the drum.

5. Set handwheel to .005 deeper than the noted reading; this will ensure a finished drum in one cut.
6. Engage the cross-feed handle for the drum slide with the ON-OFF switch to drum position.

#### **Mounting Hubless Disc Rotors**

1. Clean and check all surfaces for flatness that will come in contact with centering cones and/or bell clamps to ensure solid mounting.
2. Cleaning and properly mounting the rotor prior to machining will ensure a minimum of stock removal, better surface finish and optimum braking efficiency.
3. Excessive run out or wobble of the rotor after it has been properly cleaned and mounted on the arbor may indicate severe damage to the rotor and therefore should not be used for further service.
4.
  - a. Select proper size bell clamps and slide one on the arbor.
  - b. Slide spring on the arbor.
  - c. Find the centering cone adapter that fits the center hole of the rotor and slide it on the arbor.
  - d. Slide the rotor on the arbor and then the other bell clamp.
  - e. Add necessary spacers, (double tapered radius adapters may be used as spacers), alignment washers (make sure they are installed concave to convex), hex nut and tighten securely. Do not jerk or over tighten. (See example on page 19)
5. Silencers should be used for rotor machining.
6. If arbor appears distorted, check for rust, burrs or chips on cones, rotor, bell clamps, spacers, arbor or other mating surfaces.
7. Composite hubless rotors may require optional composite rotor adapters.

#### **Mounting Hubbed Rotors**

1. Select the double tapered radius adapter that properly fits the inside of the large bearing race. It should sit in the race similar to a bearing and move side to side in all directions easily. If it binds in any direction, this is an indication of an incorrect adapter selection or a damaged bearing race. Correct problem before proceeding.

2. Slide the double tapered radius adapter all the way onto the arbor. If the drum or rotor contacts the lathe, a spacer may be required between the double tapered adapter and lathe.
3. Using the same procedure as in Step 1, select the double tapered radius adapter for the outside race.
4. Install the rotor and position it on the back double tapered radius adapter and then slide the front double tapered radius adapter on the arbor and into the front race.
5. Use adapters or spacers as necessary to space out to the end of the arbor. (See example on page 20) Double tapered radius adapters may be used as spacers. Add alignment washers (make sure they are concave to convex) and hex nut then tighten. Do not shock load, jerk or over tighten.
6. Silencers should be used for rotor machining.
7. If arbor appears distorted, check for dirty or damaged mounting surfaces and/or adapters. Loosen and re-tighten arbor nut as described above in Step 5.

#### **Machining Hubless and Hubbed Rotors**

1. The twin cutter must be positioned in proper alignment with the rotor. Center the disc rotor between the two tool bar holders. The tool bars are fed by calibrated knobs at either side of the bars.
2. With machine running, set the tool bars for depth of cut by loosening the locking screw on top of the tool bars so that the bars will move freely when the calibrated knobs are turned.
3. Adjust cutter bars to remove the minimum amount required to finish the rotor in one cut. DO NOT MACHINE A ROTOR TO LESS THAN MANUFACTURER'S SPECIFICATIONS.
4. If surface is scored, locate the deepest score and turn the rotor micrometer knob until the tool bit bottoms out at the deepest point of the score; zero the scale and back out the tool bit. Repeat on other side. If no score exists, touch rotor with tool bit near outer edge and advance calibrated hand knob until full circle is scratched on rotor and "Zero" knob. Back out the tool bit.

5. Advance the twin cutter by handwheel until the tool bits have cleared the inner edge of the rotor face. Adjust the micrometer knobs for approximately .005 more than the first reading. This will ensure clearing the rotor in one cut. Some rotors may require optional "Zero" angle tool holders.
6. Tighten locking screws. IT IS NOT NECESSARY TO TIGHTEN THESE SCREWS DOWN EXCESSIVELY.

The replacement carbide inserts have three cutting surfaces. When sufficient wear causes an inferior finish, rotate the carbide insert to a new tip. There is a precision relief below the cutting edge: DO NOT TURN THESE INSERTS OVER.

### **Mounting Flywheels**

1. Clean the machined surfaces, so they are free of rust, dirt and burrs.
2. Select the centering cone that fits the center hole. Then select the bell clamps that fit the cones and the center **machined** area of the flywheel (you may use one large and one small bell clamp).
3. Mount the flywheel in the same manner as a hubless rotor or drum, with the side to be machined facing the lathe. (See example on pages 19 and 21)

NOTE: DOWEL PINS OR STUDS MUST BE REMOVED BEFORE MACHINING.

4. Use silencer when possible. Magnet packs or bars may be used as silencers.

### **Machining Flywheel - 100 RPM RECOMMENDED**

1. Loosen the two square head set screws on the boring bar holder; remove and insert the reverse end (small flat surface up). DO NOT TURN THE BAR OVER; ONLY TURN 180 DEGREES, END FOR END IN HOLDER.
2. The left hand edge of the tool bit insert should be at a 90 degree angle to the surface to be machined. Adjust boring bar to obtain minimum extension.
3. Turn the right calibrated handwheel (drum slide) until carbide insert makes contact with the lowest point of the flywheel; note the reading.
4. Move to the inside surface and turn the handwheel .003" - .005" greater than the noted reading. On flywheels with hard spots, the minimum depth of cut should be .012".
5. Engage the rotor cross-feed handle on the front cross slide.

6. It is recommended to use the 2" boring bar if available for flywheels.

**CAUTION:** When machining cup-type flywheels you must stay with the lathe, because you must stop the unit and re-position the tool bar for the outside lip surface. You must also remove the same amount from the outside mounting surface as was removed from the lower surface; failure to do this will cause incorrect clutch travel.

## ACCU-TURN 8989 HEAVY-DUTY COMBINATION BRAKE LATHE

### HEAVY-DUTY OPERATION PROCEDURES

#### Inspection of Brake Drums, Disc Rotors & Flywheels Before Machining

IMPORTANT: The maximum amount of metal removed from the finished workpiece should never exceed the manufacturer's specifications. It is dangerous to operate a vehicle with a drum, rotor or flywheel which has had more material removed than is allowed. Proper operation cannot be established if these specifications have been exceeded. ACCU Industries recommends that each workpiece be checked for size before mounting on the machine and after machining.

#### Mounting Heavy-Duty Hubless Drums or Rotors

1. Normally the 1 7/8" arbor is required when machining heavy duty workpieces. The 1 7/8" arbor should be installed the same as the 1" arbor (see page 7). Disregard match marks as 1 7/8" arbor has none.
2. Clean and check all surfaces for flatness that will come in contact with centering cones and/or clamps to ensure solid mounting.
3. Cleaning and properly mounting the drum or rotor prior to machining will ensure a minimum of stock removal, better surface finish and optimum braking efficiency.
4. Excessive run out or wobble of the drum or rotor after it has been properly cleaned and mounted on the arbor may indicate severe damage to the drum or rotor and therefore should not be used for further service.
5.
  - a. Select proper size bell clamps.
  - b. Install sufficient number of spacers on 1 7/8" arbor to insure that drum/rotor assembly will be mounted without contacting brake lathe housing and/or bench. Slide bell clamp on 1 7/8" arbor.
  - c. Slide spring on the arbor.
  - d. Find the centering cone adapter that fits the center hole of the drum or rotor and slide it on the arbor.
  - e. Slide the drum or rotor on the arbor and then the other bell clamp.
  - f. Add necessary spacers (double tapered radius adapters may be used as spacers), install nut and tighten securely. Do not jerk or over tighten. (See example on page 19)

6. WRAP RUBBER SILENCER BAND AROUND DRUM, STARTING WITH THE PLAIN END AND MAINTAIN TENSION UNTIL THE CLIP IS SECURED. DO NOT ATTEMPT TO MACHINE DRUMS WITHOUT USING THE SILENCER BAND. Silencer should be nearest open side of drum. Silencers should also be used for rotor machining.
7. If arbor appears distorted, check for rust, burrs or chips on cones, drum or rotor, bell clamps, spacers, arbor or other mating surfaces.

#### **Mounting Heavy-Duty Hubbed Drums or Rotors**

1. Select the double tapered radius adapter and/or cone that properly fits the inside of the large bearing race. It should sit in the race similar to a bearing and move side to side in all directions easily. If it binds in any direction, this is an indication of an incorrect adapter selection or a damaged bearing race. Correct problem before proceeding.
2. Install sufficient number of spacers on 1 7/8" arbor to insure that drum/rotor assembly will be mounted without contacting brake lathe housing and/or bench.
3. Slide the double tapered radius adapter or cone onto the arbor.
4. Using the same procedure as in Step 1, select the double tapered radius adapter or cone for the outside race.
5. Install the drum or rotor and position it on the back adapter and then slide the front adapter on the arbor and into the front race.
6. Use adapters or spacers as necessary to space out to the end of the arbor. (See example on page 20) Double tapered radius adapters may be used as spacers. Add nut then tighten. Do not shock load, jerk or over tighten.
7. WRAP RUBBER SILENCER BAND AROUND DRUM, STARTING WITH THE PLAIN END AND MAINTAIN TENSION UNTIL THE CLIP IS SECURED. DO NOT ATTEMPT TO MACHINE DRUMS WITHOUT USING THE SILENCER BAND. Silencer should be nearest open side of drum. Silencers should also be used for rotor machining.
8. If arbor appears distorted, check for dirty or damaged mounting surfaces and/or adapters. Loosen and re-tighten arbor nut as described above in Step 6.

### Machining Heavy-Duty Hubless and Hubbed Drums

1. When machining large diameter drums the recommended spindle RPM should be set to slow speed or 50 RPM's. This is accomplished by removing belt guard on rear of brake lathe and positioning belt in small pulley at the motor and large pulley at gear box. Always install belt guard before starting machine.
2. Position the 2" boring bar so that the 45 degree angle tool bit slot is toward the drum, with the capscrews to the top. BORING BAR EXTENSION SHOULD BE KEPT TO A MINIMUM. Boring bar must not be rotated upward or downward.
3. Turn on the machine. Slowly advance the boring bar in the drum and contact the point of the greatest wear.
4. Note the reading on the calibrated handwheel; back out one full turn and move to the rear of the drum.
5. Set handwheel to .005 deeper than the noted reading; this will normally ensure a finished drum in one cut. Do not increase drums diameter more than .050" per cut.
6. Engage the cross-feed handle for the drum slide with the ON-OFF switch to drum position.
7. Multiple cuts may be required on some drums.
8. DO NOT EXCEED MANUFACTURERS RECOMMENDED MAXIMUM DIAMETER.

### Machining Heavy-Duty Hubless and Hubbed Rotors

1. When machining large diameter rotors the recommended spindle RPM should be set to slow speed or 50 RPM's. This is accomplished by removing belt guard on rear of brake lathe and positioning belt in small pulley at the motor and large pulley at gear box. Always install belt guard before starting machine.
2. The twin cutter must be positioned in proper alignment with the rotor. Center the disc rotor between the two tool bar holders. The tool bars are fed by calibrated knobs at either sides of the bars.
3. With machine running, set the tool bars for depth of cut by loosening the locking screw on top of the tool bars so that the bars will move freely when the calibrated knobs are turned.
4. Adjust cutter bars to remove the minimum amount required to finish the rotor in one cut. DO NOT MACHINE A ROTOR TO LESS THAN MANUFACTURER'S SPECIFICATIONS.

5. If surface is scored, locate the deepest score and turn the rotor micrometer knob until the tool bit bottoms out at the deepest point of the score; zero the scale and back out the tool bit. Repeat on other side. If no score exists touch rotor with tool bit near outer edge and advance calibrated hand knob until full circle is scratched on rotor and "Zero" knob. Back out the tool bit.
6. Advance the twin cutter by handwheel until the tool bits have cleared the inner edge of the rotor face. Adjust the micrometer knobs for approximately .005 more than the first reading. This will ensure clearing the rotor in one cut. Some rotors may require optional "Zero" angle tool holders if tool bit contacts hub before clearing friction surface.
7. Tighten locking screws. IT IS NOT NECESSARY TO TIGHTEN THESE SCREWS EXCESSIVELY.

The replacement carbide inserts have three cutting surfaces. When sufficient wear causes an inferior finish, rotate the carbide insert to a new tip. There is a precision relief below the cutting edge: DO NOT TURN THESE INSERTS OVER.


NOTE: Left hand tool bit holder may need to be shortened to allow twin cutter to machine left side of rotor if spoke is attached. Holder can easily be shortened with hack saw.

FOR INFORMATION ON SPECIAL APPLICATIONS,  
CONTACT YOUR ACCU-TURN DISTRIBUTOR.


**Sharp Tools Are Vital To Satisfactory Operation**

When ordering supplies or replacement parts for this machine, always provide the model # and serial # of the machine. Use only ACCU-TURN parts.


PROPER MOUNTING OF HUBLESS ROTOR OR DRUM




PROPER MOUNTING OF HUBBED ROTOR OR DRUM




# PROPER MOUNTING OF FLYWHEEL





## SEALED BEARING MOUNTING



The 436271 drive assembly can be used on all industry standard 1" and smaller arbors to allow resurfacing of drums and rotors with sealed bearings, without having to remove the bearing assembly. The above illustrates a drum from a Ford Probe. Examples of this type of mounting include Toyota Vans, Dodge Caravan, Renault Alliance and others.

**8989 HEAVY-DUTY COMBINATION BRAKE LATHE  
PARTS LIST**

ITEM #	PARTS #	QTY.	REQ'D.	DESCRIPTION
1	434324	1		HOUSING
2	434014	1		COVER, HOUSING
3	434420	1		GASKET .015
4	420772	4		SCREW
6	433605	1		SPINDLE
7	433618	1		BEARING, CONE
8	433619	1		BEARING, CUP
9	433616	1		BEARING, CONE
10	433772	1		BEARING, CUP
11	433622	1		SEAL
12	431146	1		SEAL
13	433620	1		SEAL
14	408129	1		SEAL
15	433611	1		SHIM
16	433612	1		SHIM
17	433613	1		SHIM
18	411342	1		KEY
19	433606	1		GEAR, WORM
20	433974	1		SCREW, SET
21	408365	1		LOCK WASHER
22	408364	1		LOCK NUT
23	433607	1		SHAFT, WORM
24	433614	2		BEARING, CONE
25	433615	2		BEARING, CUP
26	433608	1		CARRIER, BRG.
27	421643	1		GASKETS
28	411389	4		SCREW
29	420149	1		SEAL
30	434311	1		DOVE TAIL, BOTTOM
31	433634	4		SCREW
32	433790	2		WEAR STRIP ASSY.
33	433635	1		WAY WIPER ASSY.TOP
34	433638	10		SCREW
35	434319	1		DOVE TAIL,CENTER
36	433627	1		DOVE TAIL, TOP
37	433630	8		SCREW, SET
38	413294	8		WASHER
39	413291	8		NUT, HEX
40	433639	2		SCREW, TURN
41	535638	1		SCREW, DRUM FEED ASSY.
42	433156	1		SCREW, ROTOR FEED ASSY
44	433645	4		RING, RETAINING EXT.
45	432413	4		RING, RETAINING INT.
47	433623	2		BEARING, BALL

ITEM #	PARTS #	QTY.	REQ'D.	DESCRIPTION
48	433907	2		HOUSING, FEEDBOX
49	433646	1		NUT, DRUM FEED
50	433647	1		NUT, ROTOR FEED
51	411378	4		SCREW
52	417258	2		SCREW
53	433641	2		MOTOR 1/60, 6 RPM
54	434081	8		SCREW
55	434384	2		ASSY.SHIFTING YOKE
56	434016	2		COLLAR
57	421431	2		KEY
58	434439	2		DRIVE ADAPTER
59	433974	2		SCREW, SET
60	433653	2		GEAR, SPUR 55 TEETH
61	433655	2		SPRING, CONICAL
62	433654	2		WASHER
63	421077	2		RING, RETAINING EXT.
64	433651	2		GEAR, SPUR 70 TEETH
65	433649	2		SWITCH, LIMIT
68	433908	2		COVER, FEEDBOX HSING
69	434017	2		SNAP-IN NYLINER
70	433909	2		HANDLE, SHIFTER
71	433974	8		SCREW, SET
72	1A2169	2		SPRING
73	408373	2		BALL
74	433667	2		GUARD, RTR WAY DR.MTR
76	433638	4		SCREW
77	433735	1		TELESCOPING WAY COVER ASSY.
78	433648	12		SCREW
79	433682	4		SPACER, WAY COVER
80	433688	4		SCREW
81	433687	4		SCREW
82A	433828	1		HANDWHEEL ASSY. DRUM
82B	433665	1		HANDWHEEL
82C	433666	1		HANDLE, REVOLVING
82D	433669	1		DECAL, CALIB 0-80 DRUM
82E	408409	1		SCREW
82F	433974	1		SCREW
83A	433829	1		HANDWHEEL ASSY. ROTOR
83B	433665	1		HANDWHEEL
83C	433666	1		HANDLE, REVOLVING
83D	433781	1		DECAL, CALIB 0-95 RTR
83E	408409	1		SCREW
83F	433974	1		SCREW, SET
84	433729	1		BASE, MOTOR ASSY.
85	434572	1		SHAFT, MOTOR BAS.PVT.
86	434228	3		SCREW, SET
87	434573	1		MOTOR 115/230 VOLT 1 PHASE, 1 H.P.

ITEM #	PARTS #	QTY.	REO'D.	DESCRIPTION
88	434574	4		WASHER
89	434575	4		SCREW
90	433671	1		SHEAVE
91	434576	1		SHEAVE
92	433673	1		V-BELT
93	434577	1		GUARD, BELT
94	434578	2		SCREW
95	433685	1		LAMP
96	433674	1		FITTING, RELIEF
97	413281	1		PLUG, PIPE
98	411488	32 OZ		OIL, MOBIL SYNTHETIC GEAR OIL
99	433830	TRACE		STORE-AND-LUBE
100	411478	1 OZ		GREASE #2
101	433727	1		POWER CORD ASSY.
102	433726	1		MOTOR CORD ASSY.
103	433698	1		WIRE, ELECTRICAL
108	433719	7		CLAMP, CABLE 2 SCREW
109	434734	1		CONDUIT, FLEXIBLE
110	434133	10		CONNECTOR, CRIMP-ON
111/112	434132	2		CONNECTOR, CRIMP-ON
113	433818	1		SCREW
114	434402	1		SCREW
115	438054	1		SWITCH, ROTARY
116	433695	1		DECAL, SWITCH
117	433732	1		LABEL, CAUTION
118	433733	1		LABEL, CAUTION
119	433819	1		NAMEPLATE, ACCU IND.
120	434361	1		NAMEPLATE, SERIAL #
121	433633	1		BOLT, T SLOT
122	433777	1		HOLDER, BORING BAR
123	4B4280	1		WASHER
124	433617	1		NUT, HEAVY HEX.
125	433778	1		BORING BAR
126	433780	2		SCREW, SET
127	433763	1		HOLDER, TOOL BIT
128	433771	1		SCREW, SET
129	433717	3		CARBIDE BIT & SCREW
130	434009	1		CAP PLUG
131	433974	4		SCREW, SET
132	434199	1		WAY WIPER ASSY. CTR.
133	434378	1		PATENT NUMBER PLATE
135	436266	1		FAN
137	434700	4		NUT, HEX
138	433994	5 oz.		GREASE
139	434800	1		PLUG, PUSH IN
170	434320	1		DOVE TAIL, CTR.EXT.
171	434321	2		SCREW
172	434322	1		SWITCH, ACTIV. DOVE TAIL


173	-----	434323	-----	2	-----	PIN, SPRING
174	-----	434317	-----	1	-----	TEL.WAY ASSY.
175	-----	434732	-----	1	-----	WIRE ELECTRICAL
176	-----	417555	-----	1	-----	SCREW
177	-----	434383	-----	1	-----	PLUG,BORE
178	-----	434579	-----	1	-----	SHREAVE
179	-----	433625	-----	2	-----	SET COLLAR
180	-----	434581	-----	1	-----	TENSION BAR
181	-----	413294	-----	2	-----	WASHER
182	-----	434582	-----	1	-----	SPRING SELECTOR
183	-----	421427	-----	1	-----	NUT, LOCK
184	-----	434733	-----	1	-----	CONDUIT, FLEX. DRUM WAY


**433750 TWIN CUTTER ASSEMBLY  
PARTS LIST**

ITEM #	PART #	QTY.	REQ'D.	DESCRIPTION
300	433752	1		BASE, ROTOR-TRUER
301	433753	1		BASE, CUTTER TEN. BAR
302	433754	1		BASE, ROTOR-TRUER PTR.
303	433755	1		TOOL HOLDER, R.H.
304	433756	1		TOOL HOLDER, L.H.
305	433757	1		CUTTER TENSION BAR
306	433758	1		POINTER, ROTOR-TRUER
307	433759	1		ADJUSTING WHEEL ROTOR-TRUER
308	433760	2		ADJUSTMENT SCREW
309	433761	2		CALIB. WHEEL R.T.
311	433763	1		TOOL BIT HOLDER R.H.
312	433764	1		TOOL BIT HOLDER L.H.
314	433765	2		SCREW, SHOULDER
315	420212	1		SCREW
316	420211	1		SCREW
317	433766	2		SCREW
318	433767	2		SCREW, THUMB
319	433768	2		WASHER, WAVE
320	420772	2		SCREW, DRIVE
321	433770	1		SPRING, ROTOR-TRUER
322	433771	2		SCREW, SET
323	434738	2		SPRING, BELVILLE
325	4B9806	4		SCREW, SET
326	433773	4		BALL, NYLON
307	436272	1		EXTENDED KNOB


**STANDARD ACCESSORIES**



<u>ITEM #</u>	<u>PARTS #</u>	<u>QTY.</u>	<u>REQ'D.</u>	<u>DESCRIPTION</u>
200	433702	1		BAR, DRAW
201	4B4280	2		WASHER
202	433617	2		NUT, HEAVY HEX.
203	433703	2		PLATE, FACE 1
204	433704	2		PLATE, FACE 2
205	433705	1		CENTERING CONE, DRUM #1
206	433706	1		CENTERING CONE, DRUM #2
207	433707	1		CENTERING CONE, DRUM #3
208	433708	1		ADAPTER #1
209	433709	1		ADAPTER #2
210	433710	1		ADAPTER #3
211	433711	1		ADAPTER #4
212	433617	1		NUT, HEAVY, HEX.
213	433712	1		SPACER, ARBOR
214	433715	1		WASHER, ASSY. SELF ALIGNING
215	433713	1		NUT, HEX.
216	433774	1		SPACER
217	433716	1		SPRING, ARBOR
218	433782	1		SILENCER, DRUM
219	433785	1		SILENCER, LG. VENTED ROTOR
220	433789	1		SILENCER, SMALL NON-VENTED ROTOR
221	436410	1		WRENCH, 1 1/2 BOX END
222	433963	1		ADAPTER #5
223	434558	1		WRENCH
224	434559	1		WRENCH
	433750	1		RT GROUP W/TOOL HOLDERS







VIEW C-C










TWIN CUTTER ASSEMBLY  
 #433750  
 TOP VIEW

35

TWIN CUTTER ASSEMBLY  
#433750  
FRONT VIEW




36

)

)


)

TWIN CUTTER ASSEMBLY  
#433750  
SIDE VIEW




37


38



TWIN CUTTER ASSEMBLY  
#433750  
REAR VIEW



TOOL BAR PIVOT BOLT



FOR EXPORT:  
REWIRE MAIN MOTOR  
FOR 220 VOLTS